TOOLS AND ACCESSORIES

THREAD SNIPPER

MIXING CUPS

RC 177 - PACK OF 100 \$4.39 **RC 178 - PACK OF 10** \$0.49 Clear 1 oz. plastic cups. For mixing epoxy, and finishes. A handy rod builder accessory.



SYRINGES

NEW IMPROVED

RC 350 \$1.87

1 PAIR COLOR CODED 3 cc. To ensure proper measurement

of products.



RE-CLOSABLE BAGS

T 420 - 2x3" \$3.09 \$4.13 T 430 - 3x5"

100 per bundle

Plastic mini grip bags. For reel parts, fishing hooks, small jigs and lures. Comes with a white writing block for numbers, ect.

TRIM SHEARS

Capable of cutting soft wire, monofilament line, and all thread. Economy priced light duty trim shear.



\$2.51

DIAL CALIPER

Perfect for matching handles and rod blanks. 0-5" dial caliper with .01" and 1/64th readings.



BURNISHING TOOL

A smooth contour device used to

smooth and flatten rod windings prior to the coating procedure.



CHINA MARKER

RC 526 China Marker

\$2.05

Peel-Off® White China Marker



TOP SCALE

Pacific Bay

A 104 \$3.96 Here's an easy way to match your blanks and tips.



DELUXE TRIMMER

\$7.05 By Gudebrod. High quality trimmer for wire or thread.

TOP SCALE Fuji A 105 \$5.95 Here's an easy way to match your blanks and tips.



FLEX COAT SABLE BRUSHES

Finest pure red sable makes this brush the absolute best on the market. The firm densely arranged sable provides superior control. This is the secret to applying finishe to wraps at high rpm's. Cleans up easily with epoxy brush cleaner.

RC 190 - 1/4" \$7.46 RC 191 - 3/8" \$9.37 RC 192 - 1/2" \$10.04

CALIPER

T 6 \$5.74 Perfect tool for matching handles and blanks. Measures in side and/or outside diameters.



NYLON BRUSHES

RC 193 - PACK OF 5 \$1.57 **RC 194 - PACK OF 85** \$26.65 1/8" brushes. Very low cost. Great for applying finishes and color preserve.

RC 195 - PACK OF 5 \$1.57 **RC 196 - PACK OF 85** \$26.65 1/4" brushes. Very low cost. Great for applying finishes and color preserve.

RUBBER TUBING

RC 215 - 1' **RC 216 - 1 YARD** \$1.74 Simplify your guide wrapping. Cut

tubing into 1/8" rings, then slide rings down the blank and over guide foot. Slide guides back and forth for proper spacing. Start your thread wrap and cut ring off.